

# Stainless Steel Coffee Capsule

Work For Nespresso Coffee Machine

## Use Instruction

This capsule is Compatible with nespresso coffee machine after 2010, but not cmpatible for Dolce Gusto/nespresso C150/nespresso business.

### How To Use

- 1.The first use,please kindly put the steel capsule into Nespresso coffee machine without coffee power,run it ,check and make sure that the capsule compatible your coffee machine.
- 2.Fill into about 5g coffee power ,a little pressure and cover with lid.  
(Note:in the future,according to the actual situation,increase the coffee power,press harder the coffee power,the coffee will be better,try a few times,you will be able to find a regular pattern)
- 3.Put the steel capsule into the coffee machine,close the coffee machine, run it ,use it like as nespresso original capsule
- 4.Use finished,please remove the steel capsule,clean and spare.

Note:Before use it,make sure the steel capsule clean,the holes in the lid, no coffee power on the joint.

It is Important to Experiment with Correct Amount of Coffee About 6 to 7g, (5g/spoon) and Also Pay Attention to Grind Which Can Neither be Too Coarse Nor Too Fine. Please Try a Few Times to Find the Correct One . You Will be Surprised How Good and Creamy the Coffee Is.

### About Grind



Coffee power thickness like as nespresso capsule,can be coarse than the nespresso capsule coffee powder a little.Coffee powder need uniform particle.

What kind of grind we can use?



### FAQ

Question 1: the coffee is not strong.

Cause 1:Maybe because of the coarse coffee power

Solution: Coffee power thickness must like as Nestle Nespresso capsule, coffee power need uniform particle.

Cause 2: maybe because of the fluffy coffee power

Solution: when you load the coffee,press harder and harder.

Question .:When use the steel capsule,do not come coffee or a little coffee,why?

Cause 1:maybe in the steel capsule,there is a lot of coffee power

Solution: it is better to make the capsule only 95% full of coffee power .

Cause 2:maybe the coffee power ,very close

Solution: please see the instruction,how to fill the coffee power.

Cause 3:The coffee so fine.

Solution: the coffee powder,do not like as milk power,flour.

Cause 4:The holes in the lid,be blocked.

Solution: Use finished,clean and spare.