



EasySMX



Game Controller


9013Pro USER MANUAL


Contents

English	02-06
Français	07-12
Italiano	13-17
Deutsch	18-22
Español	23-27
日本語	28-32
China	33-36

Thank you very much for purchasing our Bluetooth Controller. This is a new design that is compatible with PC, Android, Apple phones (iOS 13.0 or above with MFI games), and the SWITCH platform. Before use, please read the user manual carefully and keep it for future reference.

Controller Button Layout





- [10] LB
- [11] RB
- [12] LT
- [13] RT
- [14] Type-C
Charging Port
- [15] Reset Hole

Modes and Connections

1.Connecting to PC

Wireless Connection

Plug the wireless receiver into the PC and press the button on the front of the receiver for quick pairing. Press and hold the logo button on the controller for 3 seconds to power it on. The controller indicator LED 1 and 2 will stay on, indicating the corresponding Xinput mode.

Wired Connection

Connect the controller to the pc via the usb cable, the controller indicator LED 1 and 2 will stay on, indicating the corresponding Xinput mode.

Mode Switching

Press and hold the LOGO button for 5 seconds to switch to Dinput mode; (analog mode) LED 1 and 3 will light up.

2.Connecting to PS3 Console

Connect the USB receiver to the PS3 console. Click the HOME button briefly while the controller is in power off state. The four LED lights will flash. After a successful connection, the corresponding channel light will stay on.

3.Bluetooth Connection to Phone/Tablet

1. Android Mode: For the first connection, press B+HOME; for subsequent connections, simply press the HOME button to power on. Enter Bluetooth pairing mode, and the LED1 light will flash. After a successful connection, the LED1 light will stay on. (The device name will be "Gamepad")

2. **IOS Mode:** For the first connection, press A+HOME; for subsequent connections, simply press the HOME button to power on. Enter Bluetooth pairing mode, and the LED2 light will flash. After a successful connection, the LED2 light will stay on.

4. Bluetooth Connection to SWITCH

1) For the first connection, while the controller is powered off, press Y+HOME; for subsequent connections, simply press the HOME button to power on and it will automatically reconnect to the SWITCH. The controller's Home button can wake up the SWITCH.

2) On the SWITCH, select "Controllers," then choose "Change Grip/Order." The controller will be automatically recognized and paired with the SWITCH console. After a successful connection, the corresponding LED light will stay on.

Turbo Button Setting

1) Hold down the button you want to set as the TURBO function and then press the TURBO button once. The TURBO LED light will flash, indicating successful setting. Once set, holding down the assigned TURBO button in the game will achieve rapid firing.

2) Hold down the button set as the TURBO function and then press the TURBO button again to cancel this function.

3) In SWITCH mode, double-clicking the Turbo button will switch it to screenshot function.

Charging

1) When charging, all four LED lights will flash slowly.

2) When fully charged, all four LED lights will stay on.

3) When connected via a wired connection, the LED light indicates the current mode and will blink simultaneously to indicate the charging status. Once fully charged, the LED lights will stay on.

4) When the controller battery power is below 20%, the indicator light of the current mode will blink.

Resetting the Controller

If the controller becomes unresponsive or malfunctions during use, you can reset it. Simply use a paperclip to press the RESET hole at the bottom of the controller until you hear a "click" sound. The controller will power off, indicating a successful reset.

Package Contents

1 x EasySMX Game Controller

1 x USB Receiver

1 x USB Data Cable

1 x User Manual

1 x After-sales Card



**Follow us for the best after-sales service
and the latest news!**

EasySMX Co., Limited

Email: support@easysmx.com

Web: www.easysmx.com